




uSport


Universal Bluetooth Adapter

Mega-impact makeover for your
Bluetooth music performance



In The Box

1. uSport Universal Bluetooth Adapter
2. USB cable
3. User Manual



Getting to Know uSport

Your new uSport Bluetooth Adapter enables you to listen to music wirelessly in apt-X clarity from any devices with a 3.5mm headphone jack.

uSport works with any Bluetooth headphones, but when used with apt-X enabled Bluetooth headphones (such as the SB2 Sportsband by JayBird) your Bluetooth music experience is enhanced dramatically with cleaner, clearer professional grade audio. Visit jaybirdgear.com/aptx for more information.


uSport will provide 8-10 hours of play time between charges.



uSport features apt-X, wired audio quality for Bluetooth with a cleaner, clearer, bassier music signal. Also eliminates audio latency when viewing movies.

Charging

Charge uSport using the USB cable supplied. The charge point is next to the multi-function button as shown. Charging takes about 2 hours. Full charge is indicated by the LED light turning from red to off.



Power on/off

Hold multi-function button for 3-5 seconds to:

- a) power on/pair mode
- b) power off

LED Status

Blue/Red flashing: Pair mode

Blue flashing: Connected in SBC standard bluetooth mode

Blue double flashing: Connected in apt-X mode

Red flashing: low battery

Steady Red: Charging (turns off when fully charged)

Pairing

Pairing is the process of connecting uSport with your Bluetooth headphones. uSport remembers one paired device only. If you pair uSport with a second Bluetooth device later, you will need to re-pair the original headphones again.

To pair uSport with your Bluetooth headphones:

1. Turn uSport on by holding the multi-function button for 3-5 seconds until the LED alternates blue/red.
2. Put your Bluetooth headphones into pair mode
(see your headphones user manual for instructions if needed)
3. uSport and your headphones will find each other and pair using passcode 0000,1111,1234 or 8888. The LED will flash blue only once paired. You can now listen to your music wirelessly.
4. Plug uSport into the 3.5mm headphone jack of your music device and play your music.

If you want to pair with another device, you should turn off the original paired headphones first, and follow the above steps.

Trouble Shooting

If the connection between uSport and headphones fails, it maybe due to one of the following reasons:

1. uSport and headphones are too far apart
(range is 10 meters or 33 feet)
2. You are outdoors or in a large open space where the signal cannot bounce of walls and ceilings to achieve the full 10 meter range.
Try having the devices closer
3. Your body is getting between the devices and causing interference
(Bluetooth does not work well in water and your body is mostly water)

If you experience any unexpected behavior, and music is not playing for you, restart uSport by unplugging from your device, plug it back in and play a song. Wait a few seconds for reconnection. Also try recharging uSport incase battery is low.

Specs

Bluetooth version	Bluetooth V2.1
Bluetooth profile	A2DP
Frequency response	2.4GHZ-2.4835GHZ
Receiving sensitivity	-74±4dB
Effective range	Up to 10m
Charging input voltage	DC 5V
Lithium battery	230mAH
Working time	Up to 10 hours
Charging time	About 2 hours
Dimension	45*32*8mm
Weight	14g
codec	apt-X (or SBC in the absence of apt-X enabled Bluetooth headphones)
apt-X specs	Compression Ratio 4:1 Audio Format 16-bit, 44.1kHz (CD-Quality) Data Rates 352kbps Frequency Response 10Hz to 22kHz Algorithmic Delay <1.89ms @ Fs 48KHz Dynamic Range 16-bit: >92dB THD+N -68.8dB

Notices

Keep product dry to avoid affecting the interior circuitry of the product.

Don't put the product in direct sunlight or place in hot areas.

High temperature will shorten the life of electronic device.

Don't expose to extreme temperatures, it may damage the internal circuit board.

Don't take the product apart, or the warranty will be voided.

Don't drop the product.

Don't use chemical or detergent to clean the product.

Battery is recycled.

Do not dispose of the battery in fire as it may explode.

If the product is not working, contact JayBird support at jaybirdgear.com

Warranty Information

jaybirdgear.com/warranty



jaybirdgear.com
+1.866.244.3399 | support@jaybirdgear.com

WARNING: Due to the isolating characteristics of these earphones do not use while driving, riding a bike or where vehicular traffic is present, or in any other activity where failure to hear surrounding sounds could be dangerous. Use of these earphones at excessive volumes may cause permanent hearing damage. Always turn the volume down before use.

Copyright 2009 JayBird Gear LLC. All rights reserved. JayBird, and the JayBird logo are trademarks of JayBird Gear LLC. Bluetooth is a trademark owned by Bluetooth SIG, Inc. USA, and licensed to JayBird Gear LLC. iPhone is a trademark of Apple, Inc., registered in the U.S. and other countries. Assembled in China

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications to device will void the user's authority to operate the device.



BAU uSport Universal Bluetooth Adapter
User Manual



jaybirdgear.com